

IMPORTANT: Read And Understand All Instructions Before Installation • QUESTIONS? CALL 1-800-982-1180

LIGHT BAR

Time To Install: Approx. 20 Minutes

Tool Needed: T-40 Torx Bit and 9/16" Socket



PHOTO 1



PHOTO 2A



PHOTO 2B

1. Begin by removing the top two bolts along the outer windshield mount on both sides by using a T-40 torx bit (See Photo 1).

2. Align the mounting brackets with the flat edge facing forward and the form facing the middle of the vehicle (See Photo 2A). Replace the factory bolts and finger tighten them (See Photo 2B).



PHOTO 3A



PHOTO 3B

3. Note: It is recommended that two people perform this Step.

Lift the light bar into position and align with the upper mounting holes (See Photo 3A). Use the supplied bolts and washers to secure the light bar and tighten with a 9/16" socket (See Photo 3B).

4. Tighten up the mounting brackets and you're finished (See Photo 4).



PHOTO 4

RealWheels Corporation • 3940 Tannahill Drive • Gurnee, IL 60031

847-662-7722 • Fax 847-662-7744 • www.realwheels.com • info@realwheels.com • toll-free 1-800-982-1180