

MOUNTING OPTIONS FOR POLY HALF & FULL TANDEM FENDERS

1 YOU MUST HAVE POLY HALF & TANDEM END SUPPORT KIT

HTE100



- 2 x Tandem joining plates
- 4 x 1 5/8" clamps
- 2 x Balota anti-vibration washer
- 1 x Hardware

2 CHOOSE YOUR UNDER MOUNTING TUBES FOR YOUR HTE100 KIT

FK-02



- 2 x 1 5/8" x 30" Cranked single bolt stainless steel mounting tubes
- 2 x Anti slip washer
- 2 x Tube end cap (fitted)
- 2 x Zinc plated washer and nut

FK-03



- 2 x 1 5/8" x 30" Cranked single bolt e-coat mounting tubes
- 2 x Anti slip washer
- 2 x Tube end cap (fitted)
- 2 x Zinc plated washer and nut

Black

3 CHOOSE YOUR FRONT MOUNTING TUBES

FK-05-2



- 2 x 2" x 28" Silver powder coated mounting tubes
- 2 x Zinc plated tube clamps
- 2 x Tube end cap (fitted)
- 6 x Black plates
- 1 x All hardware

FK-04-2



- 2 x 2" x 28" Black e-coat mounting tubes
- 2 x Zinc plated tube clamps
- 2 x Tube end cap (fitted)
- 6 x Black plates
- 1 x All hardware

DON'T FORGET YOUR POLE MOUNT!

USTS200



- 1 x Single bolt post
- 8" Long
- Packaged individually

FK-02



- 2 x 1 5/8" x 30" Cranked single bolt stainless steel mounting tubes
- 2 x Anti slip washer
- 2 x Tube end cap (fitted)
- 2 x Zinc plated washer and nut

FK-03



- 2 x 1 5/8" x 30" Cranked single bolt black e-coat mounting tubes
- 2 x Anti slip washer
- 2 x Tube end cap (fitted)
- 2 x Zinc plated washer and nut

4 CHOOSE YOUR FIXING BRACKETS...

IF USING FK-02 OR FK-03 ON THE FRONT OF THE TANDEM

USUB42KIT



IT42-4



IT42HD-4

