


Valve Stem Stabilizer — Easy And Secure Installation

If a valve extension is being installed for the first time, make sure it is securely attached to the wheel valve stem.



Place the rubber valve stem stabilizer up to the valve extension and align the stabilizer's center hole with the valve extension tip.



Continue pushing the rubber stabilizer into the wheel hole until the stabilizer's front face is completely seated onto the face of the wheel.



If possible, check between the duals to make sure the flange of the stabilizer has come through the hole in the backside of the wheel and is seated around it.

RealWheels Corporation ● 3940 Tannahill Drive ● Gurnee, IL 60031 1-800-982-1180 ● 847-662-7722 ● Fax 847-662-7744 ● www.realwheels.com